

# Smart Water Intake Tracker


The Smart Water Intake Tracker is a physical, non-intrusive system that helps users track their daily water intake through passive sensing and dynamic feedback.

It consists of a smart sensing coaster and a desktop display gauge, allowing users to track hydration progress without relying on screens or manual input.

## Smart Water Intake Tracker


A non-intrusive, physical system for tracking daily water intake through passive sensing and dynamic feedback.

- This project consists of a smart sensing coaster and a desktop display device that together track and visualize a user's daily water intake.
- By passively detecting drinking events through weight changes and presenting progress via a mechanical gauge, the system encourages hydration without relying on screens or manual input.



## Sensor Device: Smart Coaster

# Sensor Device: Smart Coaster



## How it works

- The sensing device is a smart coaster placed under a cup or bottle that detects drinking events by monitoring weight changes.
- A load cell measures the applied force, and the signal is amplified, digitized, and processed by a microcontroller to estimate water intake from relative weight differences over time.

## Key components

- RGB LED: NeoPixel
- Load Cell: TAL221 (100g)
- Load Cell Amplifier: HX711
- Microcontroller: Seeed Studio XIAO ESP32-C3
- Communication: Bluetooth Low Energy (BLE)

## How it works

The sensing device is a smart coaster placed under a cup or bottle that detects drinking-related events by monitoring weight changes.


A load cell measures the applied force, and the signal is amplified, digitized, and processed by a microcontroller to estimate water intake based on relative weight differences over time.

## Key components

- **RGB LED:** NeoPixel
- **Load Cell:** TAL221 (100g)
- **Load Cell Amplifier:** HX711
- **Microcontroller:** Seeed Studio XIAO ESP32-C3
- **Communication:** Bluetooth Low Energy (BLE)

## Display Device: Desktop Hydration Gauge

# Display Device: Desktop Hydration Gauge



## How it works

- The display device is a desktop hydration gauge that provides an ambient, glanceable view of daily water intake.
- A mechanical needle shows progress from 0–100%, an RGB LED ring gives color-coded feedback, and a physical reset button allows daily tracking to be restarted.

## Key components

- Stepper Motor
- RGB LED Ring: NeoPixel
- Microcontroller: Seeed Studio XIAO ESP32-C3
- OLED: Show the number
- Rotary encoder: Set/Change the goal
- Reset button
- Communication: Bluetooth Low Energy (BLE)

## How it works

The display device is a desktop hydration gauge that provides an ambient, glanceable view of daily water intake.


A mechanical needle shows progress from 0–100%, an RGB LED ring provides color-coded feedback, and a physical reset button allows daily tracking to be restarted.

## Key components


- Stepper Motor**
- RGB LED Ring:** NeoPixel
- Microcontroller:** Seeed Studio XIAO ESP32-C3
- OLED** (Show the number)
- Rotary encoder** (Set/Change the goal)
- Reset button**
- Communication:** Bluetooth Low Energy (BLE)

## System Architecture

# Device-to-device communication



# System workflow



## Device-to-device communication

The smart coaster sends processed intake data to the display device wirelessly using Bluetooth Low Energy (BLE).



Only high-level intake events (e.g., estimated water consumed) are transmitted, minimizing bandwidth and power usage.

## System workflow

1. The load cell detects weight changes when the user interacts with the cup
2. The HX711 amplifies and digitizes the signal
3. The microcontroller filters noise and detects valid drinking events
4. Estimated intake values are accumulated locally
5. Intake data is transmitted via BLE to the display device
6. The display updates the mechanical needle and LED ring in real time

This modular architecture separates sensing and feedback, making the system easier to debug, extend, and maintain.

## Schematic



## Datasheets

All component datasheets are included in the [/datasheets](#) folder of this repository.

- [TAL221 Load Cell Datasheet](#)
- [HX711 Load Cell Amplifier](#)
- [Seeed Studio XIAO ESP32-C3](#)
- [WS2812B RGB LED](#)